

-TABLE OF CONTENTS-

1 SYMBOLS AND DEFINITIONS

2 DESIGNATION OF WHEEL SHAPE

2.1 BASIC CORE SHAPE

2.2 SHAPE OF THE ABRASIVE SECTION

2.3 LOCATION OF THE ABRASIVE SECTION

2.4 MODIFICATIONS

3 PREFERRED DIMENSIONS

3.1 DIAMETER

3.2 BORE SIZE

3.3 RIM WIDTH - PERIPHERAL WHEELS

3.4 RIM WIDTH - CUP AND FACE WHEELS

4 PREFERRED SHAPES

4.1 WHEELS

4.2 MOUNTED WHEELS AND POINTS

5 DIMENSIONAL TABLES FOR PREFERRED SHAPES

6 GLOSSARY OF TERMS

To order this book, download and fill in the appropriate order form below, and send it back to us by e-mail at j.lopes@fepa-abrasives.org, or by fax: 0033 (0)1 4581 62 94.



[Order form for FEPA MEMBERS](#)



[Order form for NON-MEMBERS](#)